

Microfiber Autoscrubber Pads for i-mop® Usage Guide

Custom disc driver and microfiber pads for i-mop XL



1. Put machine in store position.

Remove any attachments (i.e. brushes) from the machine by holding the scrub deck firmly with one hand and turning the right attachment a quarter turn clockwise and the left attachment a quarter turn counter-clockwise. You should feel resistance or see the motor disc turning. Pull attachment toward you to remove.



2. Attach Connector pad to i-mop driver disc.

Place the Connector pad on the hooked side of the Connector (printed side) disc. Make sure to align the holes on the disc with the connector pad.



3. Attach microfiber autoscrubber cleaning pad to connector pad.

Place the microfiber autoscrubber disc cleaning side down on the table (print-side up, where applicable) and center the connector pad on top of the cleaning pad.



4. Attach the driver disc to the machine.

Attach the connector driver to the machine by aligning the latches on the disc and machine.

If your i-mop has a factory-installed splash guards, see addendum on this guide.

Turn the left disc a quarter turn clockwise and the right disc a quarter turn counter-clockwise until you see the motor disk turning.



5. Use i-mop.

Take the machine out of store mode and operate the machine according to i-mop operating instructions.



6. Change pads as needed or according to soil load.

Fluid will flow through fluid ports on the Contec disc driver to the microfiber pad. Discard the pad when maximum soil load is reached.

DISCLAIMER: The following document is intended to serve as a tool to provide documentation of competency only and is in no way providing certification of the information in this document. Facilities should follow their own guidelines, policies and procedures which, in all cases, will take precedence over this training document.

Addendum: Splash Guard Removal

On some i-mop® models, factory-installed splash guards may interfere with installation of the Contec Professional® autoscrubber pad driver. Because the Contec microfiber autoscrubber pad system controls solution and prevents splashing, splash guards are not necessary and must be removed for proper installation.



1. Locate splash guards on the i-mop.

Identify the splash guard mounted in the channel near the pad driver area.



2. Slide the splash guard out

Using pliers, firmly grasp one end of the splash guard. Pull the splash guard straight out of the channel until it is fully removed.



3. Install Contec Professional Pad Driver

Attach the Contec Professional Autoscrubber Pad Driver according to Contec installation instructions.

Operate the i-mop machine following the manufacturer's standard operator instructions.