

# High Duster LT with Premira® Microfiber Covers Usage Guide

Clean hard-to-reach areas in mission critical environments



**1. Don appropriate PPE according to your facility's SOPs.**



**2. Attach the Dusting Sleeve**

Find the opening at the base of the Premira cover, and install the cover onto the dusting tool.



**3. Adjust the Tool**

Adjust the angle of the dusting head to fit your cleaning task. Press the button at the base of the dusting head to pivot.



**4. If damp dusting, Moisten the Dusting Sleeve**

Saturate the microfiber sleeve with the approved cleaning chemistry of your choice. Do not over-saturate. Sleeve should be damp, not dripping.



**5. Dust the Area**

Use smooth, controlled strokes to dust vents, lights, mission-critical equipment, or high surfaces. Continue until the cover is visibly dirty or task is complete.



**6. Remove & Dispose of the Sleeve**

Pinch the retention arms at the base of the dusting head, then pull the cover off from the far end.

*DISCLAIMER: The following document is intended to serve as a tool to provide documentation of competency only and is in no way providing certification of the information in this document. Facilities should follow their own guidelines, policies and procedures which, in all cases, will take precedence over this training document.*